

## 云台平衡调节 Gimbal balance adjustment


当首次使用或更换Gopro以外的相机/镜头，或改变相机位置、重量、体积时，为了使云台达到理想的效果，那么就需要进行云台的平衡调节。

When your first used or replace other camera/lens, or changed the position, weight, volume, must be adjustable the gimbal balance.



调节平衡过程中，请确保云台和相机的电源都处于关闭的状态，如出现状况恕本公司概不负责。

When the adjusting the balance, Pls make sure the power of gimbal and camera is off, our company is not responsible for any accident.




云台各轴示意图 Diagram

### 1. 俯仰轴的平衡调节 Balance adjustable of Pitch

用手固定横滚臂使其水平，调整相机使其保持前后水平，向下垂直状态。注（可添加配重物使其达到平衡状态）


Fixed the Roll arm make it's level, adjustable the camera make it's fore&aft level, Downward Vertically. Note (Adding counter weight to reach equilibrium)



### 2. 横滚轴的平衡调节 Balance adjustable of Roll

用手固定航向臂使其水平，调整相机使其保持前后水平，向下垂直状态。注（添加配重物使其达到平衡状态）

Fixed the Pan arm make it's level, adjustable the camera make it's fore&aft level, Downward Vertically. Note (Adding counter weight to reach equilibrium)



### 3. 航向轴的平衡调节 Balance adjustable of Pan

先保持云台与水平地面平行，调整相机使其向下垂直（可参考右图）  
注（添加配重物使其达到平衡状态）

Fixed the gimbal make it's parallel to the ground, adjustable the camera Downward Vertically. Note (Adding counter weight to reach equilibrium)

